Nokia 3100b battery replacement

Written By: Sterling Fuentes



INTRODUCTION

The battery that comes with the Nokia 3100b is prone to trouble with retaining charge or charging at all. This guide shows how to replace the battery.

Step 1 — battery



- Make sure your phone is turned off.

Step 2



- Press the button on the back of the phone and slide the back panel off.
- Remove the battery by pulling it from the phone.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-18 09:02:06 AM.